

SipWithMe Classic

Simple daily care and maintenance

withme.com | 773.797.2118 | clientservices@sipwithme.com

Table of Contents

03 **Overview** (get familiar with your machine)

04 **Loading products** (refill coffee & powder)

05 **Cleaning the containers** (clean and empty waste containers)

06 **Daily operations** (reset levels and alerts)

07 **Wash functions** (run built-in cleaning cycles)


09 **Brewing unit wash** (clean the brewing unit)

10 **Washing the mixer (**clean internal parts)

Classic Overview


This overview highlights the main components you will interact with during normal use and cleaning.

Outside




- Canisters
- Cleaning tablet door
- Touchscreen
- Lock
- Cup support

Waste containers



- Solid waste container
- Drip tray

Inside components




- Cleaning tablet chute
- Brew unit
- Dispensing nozzles
- Liquid waste conveyor
- Mixer
- Door key

Loading coffee & powders

Refill products as needed to keep drinks available and tasting their best.


1



Coffee beans:

1. Open the coffee container lid (A).
2. Load the coffee beans into the container.

2




Powders:

1. Open the powder canister cover (A).
2. Load the canister without compressing the powder.

Clean waste trays

Empty and clean waste trays regularly to keep the machine running smoothly.

1




Cleaning the drip tray:

It is recommended to empty and clean the drip tray at regular intervals.

1. Remove the drip tray.
2. Remove the grid.
3. Empty and wash the tray by using a detergent solution.

2




Cleaning the solid waste canister:

1. Remove the drip tray.
2. Remove the solid waste canister.
3. Empty and wash the solid waste tray with a detergent solution.
4. Re-assemble the trays by performing steps 1-2 in the reverse order.
5. Confirm the emptying cycle through the function “Daily actions".

Function “daily actions”


Use this menu to reset alerts or confirm product and waste levels after refilling or cleaning.

1



1. Tap ⚙ from the selections screen to access the menu.
2. Enter the set password to continue.

2




1. Tap ☰ to access the menu.
2. Touch the function "Daily actions".
3. Access the function you wish.
   - Wash / rinse
   - Waste reset: to delete the “waste full” signal
4. Tap ☰ and then ⎋ to exit the menu.

Washing function


Use wash and rinse cycles for routine cleaning.

1



⚠ Before starting a wash or rinse cycle, place a container (at least 4 liters) beneath the nozzles.

2




Access to the wash / rinse menu:

1. Touch 💧 from the selection screen.
2. Select the wash or rinse cycle you want to run.

Brewing unit wash

This process takes a few minutes and runs automatically once started.


1



⚠ Only use coffee maker-specific products. The cleaning tablet chute should only be used to wash the brewing unit.

1. Open the cleaning tablet door (push down to unlock).
2. Insert the cleaning tablet into the cleaning tablet chute.
3. Start the cleaning “With tablet” cycle

2




1. When the cycle finishes, start the brewing unit rinse cycle to remove any remaining cleaning tablet residue.

Clean mixers & nozzles

Clean these parts periodically or when buildup is visible. This section continues on the next page.


1



Disassemble the mixer:

1. Detach the pipe (A) from the mixer.
2. Turn the lever (B) counterclockwise.
3. Remove the mixer (C).
4. Separate all mixer components.

4




Clean the components:

1. Wash all the components using a detergent solution. Use pipe cleaners or brushes to remove any visible buildup.
2. Rinse all parts thoroughly under running water. Dry all parts completely, especially the mixer.

Clean mixers & nozzles

(Continued).


3



Reassemble the nozzles:

1. Insert the nozzles into the support and reconnect the pipes.

4



1. Reposition the mixer impeller and push until it clicks into place.
2. Reassemble all mixer components and make sure the water funnel is fully inserted.
3. Turn the lever (A) clockwise to secure the mixer.
4. Reconnect the pipe (B) to the mixer.