

SipWithMe Elite

Simple daily care and maintenance

withme.com | 773.797.2118 | clientservices@sipwithme.com

Table of contents

03 **Overview** (get familiar with your machine)

04 **Loading coffee & powders** (refill as needed)


05 **Cleaning the waste containers** (clean and empty regularly)


06 **Daily operations** (reset levels and alerts)

07 **Cleaning internal parts** (clean the mixer, nozzles, brewer & brew unit)

Elite overview

This overview highlights the main components you will interact with during normal use and cleaning.






Loading coffee & powders

Refill products as needed to keep drinks available and tasting their best.


1



Coffee beans:

1. Open the door.
2. Lift the upper flap.
3. Slide open the lid of the canister you're refilling and fill it with coffee beans.
4. If the canister level control is active, enter the amount you loaded in "Daily operations."

2




Powders:

1. Lift the powder conveyor.
2. Remove the canister you're refilling from the shelf.
3. Lift the lid and load the canister without compressing the powder.
4. Slide the canister back into the guide.
5. If the canister level control is active, enter the amount you loaded in "Daily operations."

Cleaning waste containers

Empty and clean waste containers regularly to keep the machine running smoothly.


1



Cleaning the drip tray:

1. Hold the drip tray by its sides, lift it slightly and pull it out.
2. Separate the parts and empty out the residue. Wash the parts with a neutral detergent solution, removing all residue.
3. Reassemble the drip tray by repeating steps 1-2 in reverse order.

2




Cleaning the solid waste container:

1. Lift the cup support by pushing it upward.
2. Remove the drip tray.
3. Open the lower flap.
4. Remove the solid waste container, then empty and wash it with a neutral detergent solution.
5. Reassemble in reverse order.
6. In “Daily operations,” select, “Waste reset” to clear the “solid waste full” signal.

Daily operations

Use this menu to reset alerts or confirm product and waste levels after refilling or cleaning.

1




Accessing “Daily operations”:

1. Open the door, if enabled in the menu, tap and hold the brand logo for 2 seconds.
2. Enter the programmed access password to continue.



Keep your access password somewhere safe.

2




1. Tap the menu icon to access the menu.
2. Tap the "Daily operations" function.
3. Select the function you wan:
   - Canisters filling: to enter the amount of product loaded
   - Waste reset: to clear the “waste full” signal
   - Washing functions
4. Tap the menu icon and then the exit icon to exit the menu

Cleaning internal parts

Clean these parts periodically or when buildup is visible. This section continues on the following pages.


1



Disassembling the mixer:

1. Lift the product conveyor (D).
2. Detach the pipe (A) from the mixer.
3. Turn the lever (B) counterclockwise.
4. Remove the mixer (C).

2




Separating the mixer components:

1. Separate all mixer components.
2. Remove any visible buildup.

Cleaning internal parts

(Continued).


3



Removing the mixer impeller:

1. Gently pull to remove the mixer impeller.
2. Remove any visible buildup from the impeller.
3. Wash and rinse the blue parts under warm running water, using a clean brush and, if needed, a food-grade detergent.
4. Dry the parts with a paper towel.

4




Removing the nozzles:

1. Lift the cover.
2. Slide off the nozzle support (black part).
3. Disconnect the pipes and remove the nozzles.
4. Wash and rinse the parts under warm running water, using a clean brush and, if needed, a food-grade detergent.
5. Dry the parts completely with a paper towel.

Cleaning internal parts

(Continued).


5



Disassembling the brewer:

1. Detach the pipes from the brewer.
2. Turn the brewer to the right to release it from the cover.
3. Separate all the brewer components and remove any visible buildup.

6




Washing the parts:

1. Wash all the disassembled parts, using pipe cleaners or brushes to remove any visible buildup.
2. Clean the drink dispensing pipes with a pipe cleaner.
3. Rinse all parts thoroughly under running water.
4. Dry all parts with a clean, dry cloth.

Cleaning internal parts

(Continued).


7



Reassembling the mixer impeller:

1. Reposition the mixer impeller and push it in.
2. Make sure it is fully inserted until it clicks into place.

8



Reassembling the mixer:


1. Reassemble the mixer components and reposition the mixer.

⚠ **Make sure the mixer is correctly connected.**

Cleaning internal parts

(Continued).


9



Fastening the mixer:

1. Turn the lever (A) clockwise to secure the mixer.
2. Reconnect the pipes to the mixers.
3. Lower the powders coveyor.

10




Reassembling the brewer:

1. After cleaning all the components, reassemble the brewer.
2. Fasten the brewer to the cover.

Cleaning internal parts

(Continued).


11



Reassembling the nozzles:

1. Reconnect the pipes to the nozzles.
2. Insert the nozzles into the support.
3. Reposition the nozzle support.
4. Lower the cover.

12



Cleaning the brew unit:

Each time you refill the machine, or at least once a week, remove any coffee residue from around the brew unit.

1. Turn the upper piston nozzle to release it
2. Rotate the coffee outlet nozzle 90° and pull it toward you.
3. Turn the unit retaining lever until it is horizontal.
4. Remove the brew unit.
5. Rinse the brew unit under a water jet.
6. Reposition the brew unit by performing steps 1-4 in reverse order.